

APPENDIX A

REPLACEMENT DRAWING SHEET

1/17




FIG. 1

REPLACEMENT DRAWING SHEET

2/17






FIG.2

REPLACEMENT DRAWING SHEET**3/17****FIG.3****FIG.4**

REPLACEMENT DRAWING SHEET

4/17




FIG.5

MAINTENANCE MENU

L/C MAINTENANCE MENU	R/C MAINTENANCE MENU
----------------------------	----------------------------

ANALOG
CALIBRATIONMANUAL
CONTROLCURRENT
ALARMSOPERATING
PARAMETERS

MAIN MENU

FIG.6

REPLACEMENT DRAWING SHEET

5/17




FIG.7




FIG.8

REPLACEMENT DRAWING SHEET.

6/17




FIG.9




FIG.10

REPLACEMENT DRAWING SHEET

7/17




FIG. 11




FIG. 12

REPLACEMENT DRAWING SHEET

8/17




FIG.13




FIG.14

REPLACEMENT DRAWING SHEET

9/17




FIG.15




FIG.16

REPLACEMENT DRAWING SHEET

10/17




FIG.17




FIG.18

REPLACEMENT DRAWING SHEET

11/17




FIG.19

REPLACEMENT DRAWING SHEET

12/17





FIG.20

REPLACEMENT DRAWING SHEET

13/17


FIG.21



REPLACEMENT DRAWING SHEET

14/17

FIG.22



REPLACEMENT DRAWING SHEET

15/17




FIG. 23

REPLACEMENT DRAWING SHEET

16/17




FIG.24A

REPLACEMENT DRAWING SHEET

17/17

STEP 10: THE PUMP INLET VALVE OPENS
TO INTRODUCE GAS TO THE PUMP INLET

STEP 11: T3 IS REACHED

STEP 12: THE PUMP BEGINS RUNNING AGAIN
(e.g., IN RESPONSE TO THE PROPORTIONAL
INTEGRATING DERIVATIVE CONTROL LOOP
AND TRANSDUCER INPUTS)

FIG.24B